OnDemand Software One Time Username and Password Authentication

1 Download and install OnDemand software from: http://www.asttech.com/products/ondemand.htm. Click `More info` , `Run anyway` , `Next >` , `Extract` , `Install` , `Finish` .

2 Contact AST at HelpDesk@ASTTech.com and request a user authentication password for CVE OnDemand.

5 User Authentication

User Name

Password

Cancel   Continue

Don't have a User Name or Password yet?
Click here to request one.

Enter the User Name and Password provided by AST.

3 Open OnDemand

7

CVe Device ID

Status
Click "Get CVe Data" to locate and retrieve data from CVe Device

Tool Info   Target Data   Scheduled Maintenance (PM)   Settings   Support   Reports

Select a Language

Storage Path for Reports   Filetype: ☑ xls/pdf ☑ Encrypted Root File
C:\ProgramData\CVeOnDemand\CVe\OnDemandReports
Currently set to:
Local Drive: DATA LOSS RISK

Network Storage is recommended

Click "Save" to continue with Local storage or browse to choose a different directory

Browse

Save

©Copyright 2018 AST Technology   All rights reserved

4 Excel Configuration Notification

ⓘ OnDemand software uses Excel to create graphs and charts containing your tools data and information. A setting in Excel must be changed to allow this to happen. If you do not complete this step then your OnDemand Reports will not be complete.

1. Open Excel
2. Select FILE
3. Select OPTIONS
4. Select TRUST CENTER
5. Select TRUST CENTER SETTINGS
6. Select MACRO SETTINGS
7. Check the box adjacent to TRUST ACCESS TO THE VBA PROJECT OBJECT MODEL
8. Select OK
9. Exit Excel

Click OK once you have completed this step

OK

Complete these steps.

6 Choose storage Path Notification

ⓘ Please choose a Storage path for defaults.

1. Click Save if default path is acceptable, or
2. Click "Browse" to select a new path followed by "Save".

OK

For complete OnDemand software instructions, please refer to the User Guide.
For technical assistance please email: HelpDesk@ASTTech.com.